

Smart Logger_SCU10 – 16 Channels Acquisition Device

USER MANUAL

Contents:

1	SCU10 Product User Manual	1
1.1	Introduction	1
1.2	Properties	1
1.3	Getting Started with the SCU10	2
1.4	Communication Protocol	3
1.5	Communication Interface	4
1.6	Voltage Acquisition	6
1.7	Synchronization	10
1.8	Standalone Mode	11
1.9	Copyright	13
1.10	Contact	13

Chapter 1

SCU10 Product User Manual

1.1 Introduction

The **SCU10** is a programmable voltage acquisition device with 16 channels, 16 bits precision and up to 100 kHz rate. It offers three communication interfaces, **Ethernet TCP**, **USB-C** and **RS-232**, to configure the parameters of the voltage input channels and receive the acquisition data.

Also, the **SCU10** is able to run in a standalone mode without a host, by saving the acquisition data in its built-in micro SD Card.

1.2 Properties



- 16 channels differential voltage measurement with 16 bits precision and up to 100 kHz rate.
- Selectable voltage input range $-/+ 10\text{ V}$ and $-/+ 20\text{ V}$.
- Ethernet TCP, USB-C and RS-232 communication interfaces.
- Built-in SD Card to store the configurations and the data acquisitions.
- Software defined and external trigger signals support.
- External clock reference for synchronization.
- Ready to use C# and LabVIEW APIs.

1.3 Getting Started with the SCU10

To start using the SCU10, we need to provide a power supply source and a communication link.

Note: In the **standalone mode**, we only need to provide the power supply for the SCU10 to work. The operation can start and store the data using the SD Card. Check [Standalone Mode](#) section for more information.

1.3.1 Power Supply

1. Connect a 24V power supply through the DC power connector.
2. Check the LED on the front panel. If the LED is on, then the board is powered on.

1.3.2 Communication Link

If the **USB-C** cable is used for the communication:

- The device driver provided should be installed.
- Check that the USB COM Port of the device is detected.
- Open the COM Port to start the communication.

If the **RS-232** port is used for the communication:

- Configure the UART to the default parameters (baud 921600, data bits 8, stop bit 1, no parity bit).
- Open the COM Port to start the communication.

If the **Ethernet** interface is used for the communication:

- Connect the SCU10 to your IP local network.
- Optionally, it is useful to ping the IP address to make sure it is connected to the network.
- Establish the TCP connection with the configured IP address and port number (IP address 192.168.0.11, port 6025).

After establishing the connection with the SCU10, send the following command to make sure the communication is working:

```
@11_HELLO;
```

The board should say hello back:

```
#11_HELLO;
```

1.3.3 Check the Software Version

The SYSID command can be used to check the current software version of the device, as well as its resources:

- **Syntax:**

```
@n_SYSID=[<Param>];
```

- **Description:**

<Param>: Optional Parameter:

- *RESOURCES*: When this token is used, the command will return the list of available resources count on the device.

If no parameter, this command returns the software version of the device and board ID number.

- **Response:**

The command is sent without parameters:

```
#n_SYSID=<Software Version>;
```

The command is sent with RESOURCES parameter:

```
#n_SYSID=RESOURCES,<Resource channels>;
```

- **Example:**

To get the current software version:

```
@11_SYSID;  
#11_SYSID=SCU10_01_01_02_03;
```

To get the available resources of the device:

```
@11_SYSID=RESOURCES;  
#11_SYSID=RESOURCES,VI16;
```

1.4 Communication Protocol

To send a command to the SCU10, the message always starts with '@' and ends with ';', and it includes the ID of the device, the command and its parameters in the right order.

Once the device receives the command, it checks the ID and if it matches, it executes the command and sends back a response starting with '#' and ending with ';'.

The following is an example of a command and response exchange between a host and the SCU10, to get the device's software version.

Command:

```
@11_SYSID;
```

Response:

```
#11_SYSID=SCU10_01_01_03_04;
```

1.4.1 Commands List


The following is the full list of the SCU10's commands:

Command	Description	Example
HELLO	Say hello to the device.	@11_HELLO;
SYSID	Get the software version of the device.	@11_SYSID;
UNIT	Control the state of the device (ON or OFF).	@11_UNIT=OFF;
ETH	Set and get the ethernet's configuration.	@11_ETH;
RTC	Set and get the real time clock parameters of the deviec.	@11_RTC;
STOR-AGE	A set of commands to manage the SD Card.	@11_STORAGE=SIZE;
CALBRT	Set and get the calibration parameters (Scale, Offset).	@11_CALBRT=VIN,1, FS,1.453;
CONFIG	Configure the parameters of voltage channels.	@11_CONFIG=SAMPLING, CHANNEL,V,2,1;
TSTRT	Validate the configuration.	@11_TSTRT;
TSTOP	Reset the configuration.	@11_TSTOP;
GETVOLT	Get the analog measurement channel's voltage value.	@11_GETVOLT=2;
SAMPLING	Start and stop the voltage aquisitions.	@11_SAMPLING=STOP,V,2;

1.5 Communication Interface

A control host can communicate with the SCU10 via the **USB-C 2.0** connection, or over an IP network via **TCP** with the 10/100 Mbps Ethernet link.

1.5.1 RS-232 Communication



The SCU10 has one RS-232 port that can be used for the communication with the device. The default parameters of the UART are the following:

Baud
921600

Data Bits
8

Stop Bit
1

Parity
None

1.5.2 USB-C Communication

The SCU10 has one USB Port 2.0 type C that can be used for the communication with the device. It is detected as an USB COM Port and can be used with any serial terminal.

Note: Install the provided device driver before you connect the SCU10.

1.5.3 Ethernet TCP Communication

If the Ethernet interface is used for the communication, the default parameters are the following:

Protocol	TCP
IP address	192.168.0.11
IP mask	255.255.255.0
Port number	6025

These parameters are not fixed, and can be changed using commands.

Set the IP Addresses

To change the source, gateway or mask IP address of the device, the user should send the following command.

- **Syntax:**

```
@n_ETH=<IP type>,<IP Address>;
```

- **Description:**

- **<IP type>**: the type of the IP address to change. A valid IP type is: SOURCE, GATEWAY and MASK.
- **<IP Address>**: the new IP address to be set. The format is four decimal values separated by ..

The command changes the source IP address of the device to 192.168.0.131.

- **Response:**

```
#n_ETH=<IP type>,<IP Address>;
```

- **Example:**

```
@11_ETH=SOURCE,192.168.0.131;  
#11_ETH=SOURCE,192.168.0.131;
```

Get the IP Addresses

To see the current Ethernet configuration of the device with the IP addresses, the user should send the following command.

- **Syntax:**

```
@n_ETH;
```

- **Description:**

The response of the command contains the type of IP address followed by the current IP address set for the source, gateway and mask addresses.

- **Response:**


```
#n_ETH=SOURCE,<Source IP Address>,GATEWAY,<IP Address>,MASK,<IP Address>;
```

- **Example:**

```
@11_ETH;
#11_ETH=SOURCE,192.168.0.11,GATEWAY,192.168.0.210,MASK,255.255.255.0;
```

1.6 Voltage Acquisition

The SCU10 offers 16 channels of differential voltage inputs, with a precision of 16 bits, accessible from the 32 pins connector on the front panel. The channels support two modes of operation, the **Single Mode** and the **Sampling Mode**.



01: VIN1+	09: VIN5+	17: VIN9+	25: VIN13+
02: VIN1-	10: VIN5-	18: VIN9-	26: VIN13-
03: VIN2+	11: VIN6+	19: VIN10+	27: VIN14+
04: VIN2-	12: VIN6-	20: VIN10-	28: VIN14-
05: VIN3+	13: VIN7+	21: VIN11+	29: VIN15+
06: VIN3-	14: VIN7-	22: VIN11-	30: VIN15-
07: VIN4+	15: VIN8+	23: VIN12+	31: VIN16+
08: VIN4-	16: VIN8-	24: VIN12-	32: VIN16-

1.6.1 Single Mode

The single mode is used to get one single voltage measurement from a channel by sending the GETVOLT command.

- **Syntax:**

```
@n_GETVOLT=<channel>;
```

- **Description:**

- **<channel>**: defines the voltage input channel number in the SCU10. Valid value is 1~16.

- **Response:**

```
#n_GETVOLT=<channel>,<voltage value>;
```

The response of the command returns the voltage value measured at the moment the command was received. Valid value is a decimal number in the range -/+ 10 V or -/+ 40V depending on the range programmed.

- **Example:**

```
@11_GETVOLT=11;
#11_GETVOLT=11,6.094217;
```

The voltage measured on the channel number 11 is 6.094217 V.

1.6.2 Sampling Mode

The sampling mode of the acquisition is used to measure the voltage channels continuously or for a time window, with a sampling rate up to 100 kHz. To use this mode, the user needs to configure first the acquisition parameters and once the configuration is set and validated, the sampling operation can be started and stopped, with the voltage data values being pushed automatically to the host or saved in the SD Card in the stand alone mode.

Channel Configuration

To set the acquisition parameters of the channels, the CONFIG commands is used.

- **Syntax:**

```
@n_CONFIG=SAMPLING,CHANNEL,V,<channel>,<mode>,<windows count>,<acq period>,
<time unit>,<sampling period>,<filter>,<amplitude>,<offset>,<>window logging>,
<graph logging>,<Compression>[TRIGGER,<trigger source>,<trigger edge>,
<precision>,<level>,<setup time>,<Holdoff>,<filter flag>;
```

- **Description:**

- **<channel>**: The voltage input channel number in the SCU10. Valid value is 1~16.
- **<mode>**: The acquisition mode for this channel. Up to 16 different modes can be defined on the same channel. Different modes can be started one after the other but never in the same time for one channel. Valid value is 1~16.
- **<windows count>**: The number of windows for the selected channel in the selected mode. Up to 16 different windows can be defined in one mode. They can be started one after the other or in the same time. One window is associated with an acquisition calculation mode. Valid value is 1~16.
- **<Acq period>**: The time period of the acquisition, starting after the trigger or directly after the SAMPLING=START command if no trigger is defined on the specified channel. Valid value is a multiple of 10 starting from 0,10 to 4294967290. The value 0 defines a continuous operation until a SAMPLING=STOP is received.

- **<time unit>**: Token specifying the acquisition period unit. Valid values are US for microseconds, MS for milliseconds and S for seconds.
- **<sampling period>**: the time between each acquisition point in microseconds. Valid value from 10 us to 1000 us with a 10 us stepping.
- **<filter>**: The filter applied on the Signal, valid value is one of the following token: SA|NONE. SA stands for Sliding Average, performed over an optimized number of points given the acquisition period and speed, not configurable, default value is 3. NONE is used for the No Filter option.
- **<amplitude>**: Amplitude of the signal in Volts. This parameter is useful when performing a RLE (Run Length Encoding) signal compression to determine the Epsilon value for the compression as 1% of the **<amplitude>** value. Valid value is a float.
- **<offset>**: This parameter is useful when performing “level” operation, it fixes the histogram calculation on the values present in the range specified with **<amplitude>** and **<offset>** parameters. Valid value is a float.
- **<window logging>**: A token to define the logging condition of window’s operation data.
 - * NEVER: only Failure Table are returned, no Data.
 - * ONFAIL: Failure Table are returned with Data of failed windows.
 - * ALWAYS: Failure Table and all data returned.
- **<graph logging>**: A token specifying if a graph of points is sent back along with the windows results.
 - * NEVER: no graph returned.
 - * ONFAIL: graph returned if any window fails.
 - * ALWAYS: graph always returned.
- **<compression>**: A token to specify the compression method used to return graph points, it can be: NONE, SUBS8, SUBS16, RLE.
 - * NONE: no compression. All points are returned up to the maximum allowed.
 - * SUBS8: oversampling, one point over 8 is returned.
 - * SUBS16: high oversampling, one point over 16 is returned.
 - * RLE: RLE operation, consecutive data points in an epsilon range are returned as one point. Epsilon is fixed at 1% of **<amplitude>** parameter.

The following parameters are optional, if a trigger event will start the acquisition.

- **TRIGGER**: Token specifying to start the trigger definition optional parameters
- **<trigger source>**: Trigger source type, INT for internal and EXT for external.
- **<trigger edge>**: Trigger to define the trigger type, RISING for rising edge, FALLING for falling edge.
- **<precision>**: The number of acquisition points used to calculate the trigger edge. Valid value is from 2 to 256 in decimal. Only power of 2 values will be internally used for calculations. If another value is used, the closest lower power of 2 values will be chosen.
- **<level>**: The level of the trigger, in channel type unit. Value is a float, for example 5.0 for a trigger level at 5 Volts.
- **<setup time>**: The time to wait after trigger event before starting the acquisition, in acquisition unit. Valid value from 0 to 65535, in microseconds.
- **<holdoff>**: The time from trigger event during which no new trigger event can occur. Valid value is from 0 to 4294967290, in microseconds.
- **<filter flag>**: A token specifying if the trigger calculation system using the filter previously defined or if it is calculated over the raw acquisition points. Valid values are FILTERED and UNFILTERED.

- **Response:**

The device sends back the configuration set in case it is valid. Otherwise, the response will contain an error message.

- **Example:**

```
@11_CONFIG=SAMPLING,CHANNEL,V,2,1,1,10,S,10,0,SA,10,DATA:NEVER,GRAPH:ALWAYS,NONE;
#11_CONFIG=SAMPLING,CHANNEL,V,2,1,1,10,S,10,0,SA,10,DATA:NEVER,GRAPH:ALWAYS,NONE;
```

This command configures mode number 1 for voltage input 1 with 1 window for a 10s acquisition at 100 kHz using the Sliding Average filter over a signal from 0V to 10V, without compression and without trigger.

Note: the above parameters: filter, amplitude, offset, window logging, graph logging, compression not implemented in the Smart Logger SCU10. The configuration is fixed in software and not accessible. They will be implemented in the next level.

Configuration Validation

After sending the configuration of all the channels to be used, the user needs to send the following command to validate the configuration:

- **Syntax:**

```
@n_TSTRT;
```

- **Description:**

The TSTRT command validates the configuration of the channels set previously.

- **Response:**

```
#n_TSTRT;
```

- **Example:**

```
@11_TSTRT;
#11_TSTRT;
```

Configuration Deletion

In case the user wants to delete the configuration of the channels, the TSTOP can be used for this purpose.

- **Syntax:**

```
@n_TSTOP;
```

- **Description:**

This commands deletes all the configuration sent previously. The channels should be stopped before sending this command.

- **Response:**

```
#n_TSTOP;
```

- **Example:**

```
@11_TSTOP;
#11_TSTOP;
```

Starting the Acquisition

After sending the configuration of the channels to be used and validating it, the command to start the acquisition of the voltage inputs is the following.

- **Syntax:**

```
@n_SAMPLING=START,V,<channel>,<mode>;
```

- **Description:**

This commands starts the voltage acquisitions immediately upon reception. In case a trigger was set, the device waits for the trigger to happen to start the acquisitions.

- **channel:** The voltage input channel number in the SCU10. Valid value is 1~16.

- **<mode>:** The acquisition mode for the channel to start.

Note: Mode is fixed in software Testing Lab and Labview, not open to change. but it work by sending command to control as user manual.

- **Response:**

```
#n_SAMPLING=START,V,<channel>,<mode>;
```

- **Example:**

```
@11_SAMPLING=START,V,10,1;  
#11_SAMPLING=START,V,10,1;
```

Stopping the Acquisition

The acquisition of the channels is stopped automatically upon reaching the time acquisition period defined in the configuration. Also, the user can stop it by sending the STOP command.

- **Syntax:**

```
@n_SAMPLING=STOP,V,<channel>;
```

- **Description:**

This commands stops the voltage acquisitions immediately upon reception.

- **channel:** The voltage input channel number in the SCU10. Valid value is 1~16.

- **Response:**

```
#n_SAMPLING=STOP,V,<channel>;
```

- **Example:**

```
@11_SAMPLING=STOP,V,16;  
#11_SAMPLING=START,V,16;
```

1.7 Synchronization

In many cases, there is a need to use and work with more than one SCU10 device to extend the voltage channels number. Therefore, these devices need to be synchronized by receiving a clock signal of **100 kHz** from the same source. This signal should be applied on the **Sync** pin 8 and **GND** pin 9, of the DB9 on the front panel.

1.7.1 Synchronization Control

To start or stop the synchronization function on the SCU10, the following command is used.

- **Syntax:**

```
@n_SYNCHRO=<action>;
```

- **Description:**

– <**action**>: **START** to enable the synchronization function, and **STOP** to disable it.

- **Response:**

```
#n_SYNCHRO=<action>;
```

- **Example:**

```
@11_SYNCHRO=START;
#11_SYNCHRO=START;
```

The synchronization function will be activated if the clock signal is applied.

1.7.2 Synchronization Status

The following command is used to check the status of the synchronization function.

- **Syntax:**

```
@n_SYNCHRO=STATE;
```

- **Description:**

The response of the command gives back the status of the synchronization function. It returns **ACTIVE** or **INACTIVE**.

- **Response:**

```
#n_SYNCHRO=<status>;
```

– <**status**>: **ACTIVE** if enabled or **INACTIVE** if disabled.


- **Example:**

```
@11_SYNCHRO=STATE;
#11_SYNCHRO=ACTIVE;
```

1.8 Standalone Mode

the SCU10 is able to run in an independant mode without the intervention of a host controller connected to the device. In this Standalone Mode, the SCU10 downloads the configuration of the input channels automatically from the SD Card at the startup and saves the results in the form of logs.

The SD Card file system is organized as a file **PARAMS.TXT** for the global parameters, a folder **MP** that contains the aquisition configurations and a folder **LOGS** that contains the saved results.



1.8.1 Standalone Parameters

The parameters of the Standalone Mode using the SD Card are stored in the **PARAMS.TXT** file. These are the configurable parameters:

- **LOGGING**: Enable (=1) or disable (=0) the logging of the results in the **LOGS** folder.
- **AUTO_READ**: Enable (=1) or disable (=0) the automatic loading the configurations at the startup of the SCU10.
- **AUTO_PUSH**: Enable (=1) or disable (=0) the board to push the results on the communication interface.

1.8.2 Test Configuration

The configuration of the channels are saved inside the **MP** folder. The user can manually connect the SD Card on the computer and save the configuration, or instruct the SCU10 to save the commands:

```
@n_STORAGE=DLSTART;  
<Configurations>  
@n_STORAGE=DLSTOP;
```

Inside the folder **MP**, we can find two types of files:

- **CONFIG.TXT**: contains the commands **CONFIG** shared by all processes.
- **MP<n>.TXT**: contains the configuration of the process with the identifier **n**.

1.8.3 Saving the Results

The SCU10 saves the results inside the folder **LOGS**, if the parameter **LOGGING** is enabled in the **PARAMS.TXT** file.

Each result is saved in one line following the same format: **<Timestamp>,<Result>\r\n**

1.9 Copyright

ART Logics is protected by copyright and intellectual property laws. Under the copyright laws, this publication may not be reproduced or transmitted in any form, electronic or mechanical, including photocopying, recording, storing in an information retrieval system, or translating, in whole or in part, without the prior written consent of ART Logics.

Warning regarding the use of art logics products. Customers are ultimately responsible for verifying and validating the suitability and reliability of the products whenever the products are incorporated in their system or application, including the appropriate design, process, and safety level of such system or application.

Products are not designed, manufactured, or tested for use in life or safety critical systems, hazardous environments or any other environments requiring fail-safe performance, including in the operation of nuclear facilities; aircraft navigation; air traffic control systems; life saving or life sustaining systems or such other medical devices; or any other application in which the failure of the product or service could lead to death, personal injury, severe property damage or environmental harm (collectively, “high-risk uses”). Further, prudent steps must be taken to protect against failures, including providing back-up and shut-down mechanisms. art logics expressly disclaims any express or implied warranty of fitness of the products or services for high-risk uses.

1.10 Contact

Tel: +86(21) 6107 5469

Cell: +86 139 1860 5295

Website: www.art-logics.com

Support: support@art-logics.com